



Transporation Equipment Supply Co.

8106 Hawthorne Drive - Erie, PA 16509

www.tescotools.com

T80480N

Injector Tip - for Use in T80481 GEVO Nozzle Kocker



T80480P

Replacement Tip for T80481 GEVO Nozzle Kocker



T80481

Fuel Injector and Fuel Pump Puller - Slide Hammer Style for GEVO Engines



The Evolution Nozzle Kocker uses the same body as the T18560 kocker with different adapters. The T80481 comes with a T80480N Adapter that threads directly into the nozzle and a T80480P Nozzle used to remove stubborn fuel pumps. These adapters are also available separately.

T80770

Fuel Line Torque Wrench, 1-1/2" Open End, 1/2" Square Drive



T81230

Nozzle Carbon Cleaner for GEVO Engines



T81310

Fuel Injector Alignment Tool for GEVO Engines



This tool is used to align the fuel injectors on Evolution Engines. The extension is milled out to profile the injector face.

T81330

Fuel Injector Sleeve Torquing Tool for GEVO Engines



The T81330 Injector Sleeve Torquing Tool has a removable 1/2" square drive extension and 4 machined tangs that fit into the injector sleeve for installation and removal.

T81350

High Pressure Fuel Line 30 MM Open End Adapter, Y Shank for GEVO Engines



The 30 MM open end adapter is used to remove and install high pressure fuel lines. It is used with the T16491 Torque Wrench.

T81830

Fuel Pump Installation Tool for GEVO Engines



T85220

Valve Setting Feeler Gages for Inlet (.45MM) and Exhaust (.95MM) on GEVO Engines



The gage has a .45 MM and a .95 MM tip attached to the knurled handle. Replacement tips are available. T85220S includes one .45 MM and one .95 MM replacement tip.

T85630

High Pressure Fuel Pump Roller Retainer for GEVO Engines



The roller retainer fits into the retainer slot in the strongback to hold up the fuel roller.

T85820

Fuel Pump Base Bolt Wrench for GEVO Engines - 12MM 12Pt, 1/2" Square Drive



T85910

Fuel Injector Sleeve Extraction Tool Set for GEVO Engines

[T85910-1](#) Puller Assembly[T85910-2](#) EZ Out Assembly[T85910-3](#) Torque Multiplier[T85910-4](#) Case[T85910-5](#) Breaker Bar[T85910-6](#) Injector Sleeve Torquing Tool[T85910-7](#) 3/4" - 10 Left Hand Nuts (5)[T85910-8](#) 1/2" F to 3/4" Male Adapter[T85910-9](#) EZ Out[T85910-10](#) Wire Brushes (3)[T85910-11](#) Plastic Brush[T85910-12](#) Crank brush assembly[T85910-13](#) Brass Washer Pick[T85910-14](#) Spare brush for crank assembly

T86501

Fuel Injector Washer Changeout Kit - GEVO Engines



T86630-AL

GEVO Aluminum Manual Fuel Injector Nozzle Remover



T86840

High Pressure Common Rail Fuel System Changeover Kit



- 1 [T16492TECH](#) 30-250 Ft-lbs adjustable, X Shank Torque Wrench
- 2 [T18220](#) 5-75 Ft-lbs adjustable torque wrench, 3/8" Ratchet
- 3 [T86790](#) Injector Alignment Tool
- 4 [T85231](#) 14mm 12 point torque adapter , x shank
- 4 [T85820](#) 1/2" Drive, 12 mm 12 point socket
- 4 [T86840-1](#) 3" extension for 3/8" Drive Socket
- 4 [T86840-10](#) 3/8" to 1/2" Adaptor
- 4 [T86840-2](#) 6 MM Hex Drive, 3/8" Drive
- 4 [T86840-3](#) 10 MM 12 Point Socket, 3/8" Drive
- 4 [T86840-4](#) 22 MM Deep Well Socket, 3/8" Drive
- 4 [T86840-6](#) 5 MM Hex Drive, 3/8" Drive
- 4 [T86840-7](#) 6 MM Long Hex Driver, 3/8" Drive
- 5 [T86840-5](#) 36 MM Deep Well Socket, 1/2" Drive
- 6 [T86860](#) Fuel Injector Puller Tool
- 7 [T86800](#) Injection Alignment Wrench
- 8 [T86810](#) Fuel line blocks
- 9 [T86830](#) Side Pipe Crow's Foot Wrench
- 10 [T85700-16](#) 16 MM 12 point, 1/2" Drive Wrench
- 11 [T17801MOE-41X](#) 41 MM open end torque adapter
- 12 [T86840-11](#) X Shank to 1/2" Ratchet
- 13 [T17801MOE-27X](#) 27 MM open end torque adapter
- 14 [T86840-8](#) Toolbox